

## Service Information



Model Any Model (Standard Mechanism)  
Serial No. \_\_\_\_\_

Subject Elimination of Squeaking Noise

No. NR-0040  
Date 2/16/82

When unexpected mechanical squeaking (scraping) noise is found when engaging in the stop mode in the Nakamichi Standard Mechanism of any model, the following procedure should be tried to eliminate it unless any other specific cause can be pointed out.

1. Remove the Top Cover.
2. Locate the Cam Drive Gear (OC08186A) indicated in the figure of the mechanism.  
\*This gear is directly driven by the cam control motor through the rubber belt.
3. Put a little drop of oil onto the shaft of the Cam Drive Gear.  
\*Use high quality oil. (Clock oil, etc.)  
\*Put the oil on both sides of the shaft as indicated in the figure.  
\*Do not use too much oil.
4. Engage the play and stop mode repeatedly and make sure that the gear will move without making any noise.

